



Sterilization of Saffguard

When used in archival, pharmaceutical and hospital applications it is often necessary to have the Saffguard act as a carrier through a sterilization system.

1. Saffguard may be wiped down with alcohol with no effect on the material.
2. **Ethylene oxide gas** sterilization has no effect of an kind on Saffguard and may be repeated any number of times.
3. One of the most damaging forms of sterilization is by the use of gamma radiation. A single treatment is not critical; however 4-5 exposures to the Standard AECL-2.5 mega rad dose will be sufficient to make the polymer brittle and initiate breakdown.



SHISH INDUSTRIES LTD
We make better...

Manufacturer of P.P. Hollow Sheet & Air bubble film

CIN : U25209GJ2017PLC097273

Reg. Offi. & Factory : Survey No. 265/266, Block No. 290, Plot No. 18 to 23, B/1 Paiki 1, Pipodara - 394 110. Ta. Mangrol, Surat (Guj.) INDIA.

Tel : +91 261 2550587. E-mail : info@shishindustries.com
web : www.shish.co.in